



# Cable Stripper Adjustable 4.5-25



HT-325B  
6"(150mm)

## Operation:

1. Turn the adjusting nut A to get the correct exposed length of blade for the cable and blade height.
2. Turn adjusting screw B to get the approximate cable diameter (not critical). This diameter is indicated on cable diameter guide C
3. Open the tool by pushing D upwards, and insert the cable between the blade and the V-shaped holder E and release.
4. Rotate the tool 2-3 times in a clockwise direction, to cut round the cable.
5. Swivel the blade by pushing the shaft, and pull the stripper along the cable, to make a longitudinal cut.
6. Use the sharp edge of the insulation lever F to lever insulation from conductor if necessary.

## Specification :

### Item no

- HT-325B

### Dimension

- 150\*48\*23mm

### Function

- Strip cables from 4.5~25 mm ( .18" - 1.0" ) diameter

### Material

- Body-ABS , Blade-SK5